


SR-21008

PART LIST



WARNING:

- Contains small parts, sharp points and edges.
- Adult assembly required.
- Two adults recommended.
- Do not stand, sit, kneel, lean or pull on unit for support.
- Never leave children unattended.
- Adult supervision recommended.
- Do not place unit near high heat.

HARDWARE




X4
(M8*100)

TIP!
DO NOT FULLY
TIGHTEN SCREWS
UNTIL ALL SCREWS
HAVE BEEN LOOSELY
POSITIONED.

BEFORE
ASSEMBLING,
MAKE SURE THERE
ARE NO
MISSING PARTS.

NOTE / HINWEIS:

AN ELECTRIC SCREWDRIVER
WILL BE RECOMMENDED FOR
ASSEMBLY (NOT INCLUDED)





CAUTION:

- Do not allow children to climb on shelves.
- Do not use as a ladder or cart.

CARE AND CLEANING

- Clean wood with a damp cloth or sponge using warm water and mild soap. Wipe dry.
- Check for loose or worn parts periodically and tighten or replace as necessary
- Do not place unit near high heat.

Record the Batch-Number here. Information is located on the shipping carton and / or the product itself. Keep this sheet in an accessible place.

Model Number: **SR-21008**


Batch-Number: _____

Distribution:
Wisdom Education Europe
Zum Poppschen Gut 3
09526 Olbernhau
GERMANY

www.wisdomeurope.com



safety range of product/Sicherheitsabstand:3960*4545MM



INSTRUCTION MANUAL

Description: Pony Spring Rider (PE Panel)

Item Code: **SR-21008**

Imported into EU by: Wisdom Education Europe GmbH, Zum Poppschen Gut 3, 09526 Olbernhau/Germany

Manufacturer: Wisdom Educational Product Co.,Ltd

Manufacturer Address: Building 4, Lane 2777, Baoan Road, Malu Town, Jiading District, Shanghai, China

Test standard: EN 1176-1:EN 1176-3

Overall Dimension: 88*33*97 CM


Weigt: NW:23KG,GW : 25KG

INSTALLATION INSTRUCTIONS

- 1.Ensure the area is safe and devoid of any hazards prior to assembly,The minimum space will be:250*250cm.
- 2.A minimum of two adults are required for assembly.
- 3.The product and materials are intended for indoor or outdoor use under supervised conditions.
- 4.Check the quantity of spare part based on spare part list before assembly.
- 5.When installing,ensure ground is either a soft fall surface,or protected by a soft material such as cardboard or a blanket when assembling to avoid frame scratching.
- 6.Tighten all bolts after assembly.
- 7.Removal all assembly materials and tools from the play area before the equipment is used.
- 8.During the process of incomplete installation, disassembly, or maintenance, the children should stay away from the product to ensure safe.
- 9.The product can be fixed to the ground, and the below is the assembling intruction.


Instruction of anchor for grass ground

- 1: Locate the footing position, dig a hole in size 600x600x900mm.
- 2: Make concrete base with 140mm height, and put in-ground kit.
- 3: Pour concrete again with 660mm height.
- 4: Cover by soil with 100mm height.
- 5: Confirm the location of pony spring rider, dig a hole and put in the in-ground kits, then pour concrete to make the fondation. (NOTE: Please keep the concrete level below the square plate!)
- 6: Align the in-ground kits with the corresponding holes on the spring rider.
- 7: Insert corresponding hardware and tighten



Instruction of anchor for cement floor

- 1: Confirm the location of pony spring rider (PE Panel) and mark the pilot holes.
- 2: Drill $\phi 12 \times 100$ vertical holes on the marked positions.
- 3: Insert corresponding hardware and tighten.



INSTRUCTIONS

1. Please read the instructions and warning labels carefully before use.
2. Inspect items and play area for any potential hazards prior to use.
3. Maximum number of people using the equipment at the same time is 1 .
4. User age group: 3 ~ 14 years old.
5. Never leave children unattended. Ensure constant adult supervision.
6. Please pay attention to the safety of the surrounding environment before use and avoid use under bad weather conditions.
7. Instruction for anchor
Anchor for grass ground: Check once a month to ensure that the embedded anchor and the self-tapping screw is not loose, and the fabric loop is not broken. If the anchor is loose, need to be covered with soil for reinforcement. If the screw is loose and fabric loop is broken, need to replace it in time.
Anchor for cement floor: Check once a month to ensure that each expansion screw is not loose. If it is loose, please replace it in time.
8. No climbing.
The height of all stepping positions are less than 60cm.
9. If the material is damaged and needs to be repaired, please contact the manufacture to repair or replace.
10. Please ensure that the installation ground is horizontal during installation and keep it horizontal during use.

MAINTENANCE

1. Clean with a moist cloth.
2. Use neutral cleaners for cleaning.
3. Regularly inspect the product.
4. Follow the below inspection cycle to adequately inspect the product.
5. Fill in the inspection record after the inspection.

INSPECTION INFORMATION

Inspection cycle	Inspection Project	YES/NO	Solution	Signature
Daily Inspection on Items	Check screws, bolts and fasteners are tightened.			
	Installed on a flat surfact and no hazards are present.			
	Equipment is free of dirt and moisture.			
	Hook and loop attachments are securely fastened.			
	Check for a signs of damage and wear.			
Monthly Inspection on Items(Except for Daily Inspection on Items)	Check screws are free of rust and damage.			
	Check parts are securely connected.			
	Check compliance labels are intact.			
Annual Inspection on Items(Except for Daily and Monthly Inspection on Items)	Check there is no extensive corrosion and replace if required.			
	Check for cracking or connecting part deterioration. Replace if required.			
	Check there is no excessive discolouration of components.			
	Check screws and connectors are in working order and not damaged or deteriorated.			
	Check compliance labels are legible.			
	Check the play area under the equipment is safe and level.			